

Serial Interface Guide

The Mesh Rider Radio runs a customized version of Openwrt with enhancements related to the Doodle Labs Mesh Rider® technology. These enhancements are useful for applications requiring low-latency command-and-control transmission and high-throughput video - e.g. UAV and robotics.

The purpose of this guide is to aide a programmer in configuring the Mesh Rider Radio Serial interface. Communications over the Mesh Rider Radio's wireless interface are IP based, so it is necessary to relay packets from the network to the serial interface. This guide includes examples of how to send data from the serial interface of one radio to that of another radio, or to simply send packets directly over the network to the serial interface.

Hardware Setup

Doodle Labs currently offers four main hardware variants in its Mesh Rider Radio lineup. UART is available on all hardware variants. However, these hardware variants have different pinouts and you should refer to the documentation package of your specific hardware for pinout information. The hardware versions can be differentiated by the model number. In all cases, the UART is implemented as one TX line, one RX line, and GND.

Please note that - 1. The legacy models (-2H-*U) have a USB host port on the auxiliary connector and have no UART port. For the UART port, you require -2H-*S model.

Connection Guide

- The UART connector is a 3-pin connector consisting of TX, RX, and GND. The TX and RX wires should be coupled closely with the GND wire for good signal integrity.
- Typically, when two devices are connected over UART, the TX wire of the first device should be connected to the RX wire of the other device and vice versa.
- While most models use 3.3-V TTL signaling, the External Mesh Rider Radio (-2J-*E) uses RS232 signaling. Please consult the documentation package of your hardware before hooking up the UART.

Serial Interface Configuration

Start with one of the hardware setups in the section above. A generic setup is shown in Figure 1.




Fig. 1 Generic UART hardware connection

Configuring the UART port using the GUI

The GUI is strictly for configuring the UART port as a Serial to Network bridge. Open up a web browser and navigate to the IP address of the Mesh Rider Radio. From there, navigate to `Services -> Serial Configuration`. A screenshot of the GUI is shown in Fig. 2. For mobile applications, we recommend using UDP transport over TCP transport as it is more responsive.




Fig. 2 UART Configuration GUI

When configuring the serial to network relay using the GUI, the program, `socat`, is used in the background. For unicast traffic, the relay should operate as either a server which listens on a particular network port for incoming connections, or a client which attempts to connect to a particular IP address and network port. For multicast traffic, the relay can either send, receive, or operate bi-directionally. **It will be necessary to open the firewall at the desired network port, and a link to the firewall page is provided.** For multicast traffic, it is also necessary to update the routing table and a link is provided to the static route page. An example static route is shown in Figure 3.

Routes

Routes specify over which interface and gateway a certain host or network can be reached.

Static IPv4 Routes

Interface	Target	IPv4-Netmask	IPv4-Gateway	Metric	MTU	Route type	
Host-IP or Network		if target is a network					
wan2	224.0.0.0	240.0.0.0	0.0.0.0	0	1500	multicast	Delete
Add							

Fig. 3 Static route configuration for multicast traffic

Choose the device `/dev/uart0`. After making your changes, click `Save & Apply`. If you are familiar with `Socat` and want to use your own arguments, then you can input them using the checkbox at the bottom of the page.

The remainder of this section discusses configuration using the CLI.

GCS Network Port Binding (Important)

Some GCS software (notably Mission Planner) do not allow the user to bind the socket to a particular network port when in client mode. Instead, the network port is assigned by the kernel. Therefore, every time Mission Planner restarts its UDP client, it will restart from a new network port. Unfortunately, this confuses socat (on the Mesh Rider Radio), and it can lead to high MAVLink packet loss.

The suggested solution is to setup `socat` in client mode and input the IP address of the GCS. In that case Mission Planner will be in UDP server mode and listening on port 14550. Alternatively, you can use the GCS Finder utility described later in this document.

Manual Configuration and Debugging the UART port

We recommend using the GUI for serial port configuration, but if you want an advanced configuration, then you may also use the CLI. This guide is not designed to be comprehensive, and if you plan on using the UART port manually, then you will need to have Linux expertise. We will discuss some of the tools which are built into the Mesh Rider Radio for you to use, and this section will also be useful as a debugging guide.

You can SSH into the radio by running

```
user@host-pc:~$ ssh root@<IP Address>
```

It may be necessary to update your PC's list of known hosts first.

```
user@host-pc:~$ ssh-keygen -R <IP Address>
```

The UART interface is attached to `/dev/uart0`.

Disable Socat

Before attempting to use the UART port manually, ensure that socat is disabled. SSH into the radio and run

```
root@smartradio:~# uci set socat.http.enable='0'  
root@smartradio:~# uci commit  
root@smartradio:~# /etc/init.d/socat restart
```

This can also be done in the web GUI.

STTY Configuration

The default UART settings can be changed using the `stty` program which is installed on the Mesh Rider Radio. An example usage is,

```
root@smartradio:~# stty -F /dev/ttyUSB0 115200 cs8 -cstopb -parenb
```

which sets the speed to 115,200 baud, 8 data bits, 1 stop bit and no parity.

(Please note that the Helix Mesh Rider Radio's UART port supports max 115,200 baud).

picocom

From the May 2021 firmware release onwards, `picocom` is installed by default on the Mesh Rider Radio. `picocom` is a terminal access program which can be used for general debugging of the UART port. You can invoke `picocom` with

```
root@smartradio:~# picocom -b 115200 /dev/uart0
```

You can exit `picocom` by holding down `CTRL`, and then hitting `a` and then `x`. For a full list of commands, just type `picocom`.

cat and echo

A single message can easily be sent on the UART port using `echo`

```
root@smartradio:~# echo -ne "Hello World\n" > /dev/ttyUSB0
```

or received on the UART port using `cat`

```
root@smartradio:~# cat < /dev/ttyUSB0
```

These programs use the settings applied by `stty` as defaults.

agetty

The program `agetty` can be used to open a serial console over the USB UART port. First access the Mesh Rider Radio over SSH, and then run

```
root@smartradio:~# agetty -8 115200 ttyUSB0 -n -l /bin/ash
```

socat and ser2net

`socat` and `ser2net` are installed on the Mesh Rider Radio, however, due to a `socat` bug, we strongly recommend that you use the web GUI for their configuration.

GCS Finder

If you are using a MAVLink-based Ground Control Station (GCS) such as QGroundControl or Mission Planner, you can use our built-in GCS-Finder utility. The connection diagram is assumed to be like that in Fig. 4.




Fig. 4 UAV GCS System

The GCS-Finder uses broadcast packets to search for MAVLink-based GCS which are listening for UDP packets on port 14550. The default behavior can be modified by navigating to `services` -> `GCS finder` in the web GUI. A screenshot is shown in Fig. 5. After enabling GCS Finder, `socat` will be disabled automatically.

The screenshot shows the 'GCS finder Configuration' page in the web GUI. The page title is 'GCS finder Configuration' and it includes a subtitle: 'This tool allows the discovery of a MAVLink-based GCS and configures ser2net to connect to it.' The page is divided into a left sidebar and a main content area. The sidebar contains the following menu items: 'Status', 'Network Configuration', 'Services' (highlighted), 'Central Config', 'GCS finder' (highlighted), 'Link Status Log', 'Serial Configuration', 'Admin', 'Advanced Settings', and 'Logout'. The main content area is titled 'General' and contains the following configuration options:

- GCS finder enabled:** (checked). Below it, a note states: 'Once the GCS finder is enabled, Socat will be disabled.'
- Broadcast IP address:** 10.223.255.255
- Source IP address:** 10.223.150.82. Below it, a note states: 'Smart Radio IP address used to communicate with the GCS.'
- Source Port:** 2000
- Connection timeout:** 30
- Baudrate of tty:** 57600
- Device:** /dev/uart0

At the bottom right of the configuration area, there are three buttons: 'SAVE & APPLY', 'SAVE', and 'RESET'.

Fig. 5 GCS finder configuration